

CONTROL (CHARGER) UNIT (X53-342X-XX) (C/5)

Q301
: 2SB798 (DL, DK)
D301, 302
: DE5SC4M
D303
: MA110
D304
: 1SS302
D305
: RD22P

(X57-) (A/4)

(X57-) (A/4)


(X57-) (A/4)

BATT TERMINAL


(X53-) (D/5)

(X53-) (E/5)

TR-RX UNIT (IF) (X57-409X-XX) (A/4) 0-11: K, P 2-71: T, X, E, E2, E3, M, M2




TX-RX UNIT (IF)




- | | | | |
|-----------------|------------------|-----------|----------|
| IC301 | : NJM4560E | D301, 306 | : MA742 |
| IC302 | : NJM2073S | D302 | : MA8039 |
| IC303, 304 | : MC3372D | D303 | : DAN222 |
| IC305 | : TA7787AF | D305 | : MA728 |
| IC306 | : S-81250HG-RD | D312, 313 | : MA110 |
| IC307 | : TC9174F | D314, 315 | : DA221 |
| IC308 | : LM301AD | | |
| | | | |
| Q301, 302, 309, | | | |
| 313, 327, 330 | : DTC144EE | | |
| Q303 | : UMG1 | | |
| Q304, 317, 318 | : 2SB1182F5 (Q) | | |
| Q305, 310, 326, | | | |
| 328, 329 | : 2SC4617 (R) | | |
| Q306, 339 | : DTA144WE | | |
| Q307 | : 2SC4215 (Y) | | |
| Q308, 325 | : DTC114YE | | |
| Q311 | : 2SK879 (Y) | | |
| Q312, 314 | | | |
| 315, 316 | : FMC4 | | |
| Q319, 320 | : FMW1 | | |
| Q321 | : FMA1 | | |
| Q322, 323 | : DTB113ZK | | |
| Q324 | : 2SC4619 (P, Q) | | |
| Q332 | : FMA7 | | |
| Q333~336 | : UMA9 | | |
| Q338 | : DTA114YE | | |

(X53-) (A/S)



- Q1 : 2SC4116 (GR)
Q2 : 2SC4116 (Y)



- IC1 : FX365LS
D1 : DAN202U

— SIGNAL LINE
— GND LINE
— +B LINE
- - -B LINE